

Installation Instructions

URIMATcompactplus

URIMATcompactinfo

IMPORTANT

- THE URINAL MUST BE INSTALLED IN ACCORDANCE WITH THE AS/NZS 3500.2 PLUMBING REQUIREMENTS.
- ENSURE THAT ALL DRAINPIPES ARE WELL CLEANED AND ARE FREE FROM BLOCKAGES.
- THE UNDILUTED DISCHARGE FROM A WATERLESS URINAL SHALL NOT BE TRANSPORTED THROUGH COPPER OR COPPER ALLOY PIPEWORK
- PLEASE GIVE THE CLEANING/MAINTENANCE INSTRUCTIONS TO THE CUSTOMER.

FittingsIncludedinInstallationKit

- MountingBracket
- Filter
- Screws+Plugs
- DrainConnector

InstallationofURIMA T

1. Drill two holes (8mm) for mounting bracket; 840mm from the floor, 255mm apart.
2. Mount the bracket using the appropriate screws & plugs for the wall. Ensure that the bracket is level.
3. Cut PVC pipe to size and push seal rubber into it.
4. Slide the urinal waste outlet into the drain connector.
5. Pull the snap action nuts on each side of the bracket toward the centre & tighten the side screws using an allen key.
6. Plug in URIMAT to the power socket (URIMATcompactinfo ONLY)
7. Seal outer edges of urinal to the wall with silicone seal.
8. Insert filter into the bottom of urinal & flush with approximately 2 litres of water to test for leaks & to activate the siphon.

