

## Installation Instructions

URIMAT **eco**

URIMAT **ecoplus**

URIMAT **ecoinfo**

### **IMPORTANT**

- THE URINAL MUST BE INSTALLED IN ACCORDANCE WITH THE AS/NZS 3500.2 PLUMBING REQUIREMENTS.
- ENSURE THAT ALL DRAINPIPES ARE WELL CLEANED AND ARE FREE FROM BLOCKAGES.
- THE UNDILUTED DISCHARGE FROM A WATERLESS URINAL SHALL NOT BE TRANSPORTED THROUGH COPPER OR COPPER ALLOY PIPEWORK
- PLEASE GIVE THE CLEANING/MAINTENANCE INSTRUCTIONS TO THE CUSTOMER.



### **Fittings Included in Installation Kit**

- Mounting Bracket
- Filter
- Screws + Plugs
- Drain Connector

### **Installation of URIMAT**

1. Drill two holes (8mm) for mounting bracket; 885mm from the floor, 310mm apart.
2. Mount the bracket using the appropriate screws & plugs for the wall. Ensure that the bracket is level.
3. Glue the drain connector to the waste pipe & grease the seal.
4. Slide the urinal waste outlet into the drain connector.
5. Pull the snap action nuts on each side of the bracket towards the centre & tighten the side screws using an allen key.
6. Plug in URIMAT to the power socket (URIMAT *ecoinfo* ONLY)
7. Seal outer edges of urinal to the wall with silicone seal.
8. Insert filter into the bottom of urinal & flush with approximately 2 litres of water to test for leaks & to activate the siphon.

