

# Installation Instructions

## IMPORTANT

- THE URINAL MUST BE INSTALLED IN ACCORDANCE WITH THE AS/NZS 3500.2 PLUMBING REQUIREMENTS.
- ENSURE THAT ALL DRAINPIPES ARE WELL CLEANED AND ARE FREE FROM BLOCKAGES.
- THE UNDILUTED DISCHARGE FROM A WATERLESS URINAL SHALL NOT BE TRANSPORTED THROUGH COPPER OR COPPER ALLOY PIPEWORK
- PLEASE GIVE THE CLEANING/MAINTENANCE INSTRUCTIONS TO THE CUSTOMER.

## Fittings Included in Installation Kit

- Mounting Bracket
- Filter
- Screws + Plugs
- Drain Connector

## Installation of URIMAT

1. Drill two holes (10mm) for mounting bracket; 875mm from the floor, 260mm apart.
2. Mount the bracket using the appropriate screws & plugs for the wall. Ensure that the bracket is level.
3. Cut sewer pipe flush to wall.
4. Glue the through connector to the sewer pipe.
5. Hang URIMAT urinal on wall brackets and connect with 90° elbow to the through Connector using the rubber seal.
6. Seal outer edges of urinal to the wall with silicone seal.
7. Insert filter into the bottom of urinal & flush with approximately 2 litres of water to test for leaks & to activate the siphon.



**Menos**™

