

## Maintenance Instruction

### Preparation

Apply grease or liquid soap to the outer edge of the new siphon insert...

...and fill with water.



### Changing Siphon Insert



Flush unit with approx.  
2 litres of water



Remove filter



Pull out siphon insert



Drain excess water  
only and dispose of siphon.



Replace with the prepared  
siphon insert.



Push down firmly on the  
new insert.

#### IMPORTANT

Ensure insert is in place,  
push down until it stops.



Insert new or cleaned  
filter.



Flush unit with approx.  
2 litres of water



Finished.

In order to get the best from your URIMAT, it is important that you follow the maintenance instructions above.

URIMAT recommends that pipework is professionally flushed once every twelve months in order to avoid potential problems from blockages.