

Cleaning Instruction for Urinals with D-Valve

Eco & Compact Line



Spray urinal inside and outside with Biox cleaner

Then wipe with clean paper starting outside

Then clean the inside



Spray urinal inside with BIOX cleaner and leave.

Finished!



D-Valve this needs to be changed on average between **2-4 times a year** depending on usage.

Base unit Adapter which the D-Valve sits in should be changed on average every 2-3 years depending on usage.

The manufacturer recommends the use of BIOX cleaning agent which is a powerful microbiological cleaning product which has no harmful chemicals and is safe to use for our ecological systems and is neither toxic nor allergenic. BIOX will eliminate the undesirable odour and provide a constant freshness in the toilet and sanitary areas.

D-Valve Order # **D001**
Base Unit Adapter Order # **D002/3**
Biox Cleaning Agent 1L Order # **80.001**
Biox Cleaning Agent 10L Order # **80.006**

Do not use any type of corrosive product that can damage the urinal or the valve.

In order to get the best from your waterless urinal it is important that you follow the maintenance instruction above.